




幽灵门铝框门款安装说明书

INVISIBLE SLIDING DOOR (ALUMINUM FRAMES DOOR)


名 称 Accessory	简 图 Drawing	单门 1 Door	名 称 Accessory	简 图 Drawing	单门 1 Door	名 称 Accessory	简 图 Drawing	单门 1 Door
主 支 架 Upper roller		1	缓 冲 器 Soft close device		2	侧 边 轮 Side roller		2
下 定 位 轮 Lower Runner		1	地 轮 Lower roller		2	ST4.5×40 十字平头自攻钉 ST4.5*40 cross head tapping screws		5
胶 粒 φ6×40 Screw anchor		5	ST4×16 十字头自攻钉 ST4*16 cross head tapping screws		6	2.0mm 六角匙 2mm Allen key		1
4.0mm 六角匙 4mm Allen key		1						

安装流程

安装步骤 installation instructions




门与门洞尺寸关系 Door Thickness Requirement



铝框门模式一（门洞全开）


Aluminum Frames Door Installation Mode 1 (complete Doorway Opening)

门宽度尺寸: $W=X+267$ Door width: $W=X+267$



缓冲器安装尺寸


Dimension for soft close device installation



铝框门模式二（门洞未全开）

Aluminum Frames Door installation mode 2 (Partial doorway opening)

门宽度尺寸 $W=X+T$ Door width: $W=X+T$
 $T \geq 150\text{mm}$ (T 必须 $\geq 150\text{mm}$)




缓冲器安装尺寸

Dimension for soft close device installation




1. 安装缓冲器

1. Insert soft close device




2. 安装侧边轮

2. Fasten side roller




3. 装入地轮和轨道

3. Fasten the lower track and lower rollers




9. 调节上下

9. Height adjustment




4. 安装门边盖

4. Install the door side cover




5. 安装上轮支架

5. Fasten the upper roller




6. 安装下定位轮

6. Fix the lower runner




10. 调节左右

10. Left and right adjustment




7. 把安全扣按回去

7. Reset the safety-catch



8. 挂门

8. Hang up the door



11. 打开锁扣

11. Lock the safety-catch

